



Trouble Shooting Guide for Printing Inks with Expancel[®] Microspheres

Expancel[®] 

Nouryon



Properties of the Printing Ink

● Dispersion

Problem	Cause	Action
Problems to disperse WU, difficulties to achieve a homogeneous dispersion.	<ul style="list-style-type: none"> • Expancel® microspheres does not hold room temperature - frozen microspheres • The mechanical agitator is broken • The WU has dried • Wrong or too little dispersant 	<ul style="list-style-type: none"> • Let the microspheres thaw to room temperature before mixing • We recommend a Silverson mixer (or dissolver) • Seal the WU bag after use • Add dispersant
The dispersion foams	<ul style="list-style-type: none"> • Defoamer absent 	<ul style="list-style-type: none"> • Add antifoam agent, e g Nopco/ Foamaster ENA 515
The microsphere settle or flotata in the ink	<ul style="list-style-type: none"> • Incorrect rheology in the ink 	<ul style="list-style-type: none"> • Add thickener
The microspheres expand	<ul style="list-style-type: none"> • Too powerful dispersion - heat development 	<ul style="list-style-type: none"> • Decrease the mixing time • Check the temperature during the process • Cool the preparation container

● Color

Problem	Cause	Action
The ink discolors during storage	<ul style="list-style-type: none"> • Too high pH • Chemical agitation 	<ul style="list-style-type: none"> • Adjust pH or consider other Expancel® grades • Identify the component affecting the microspheres

● Print

Problem	Cause	Action
Too "fluffy" print - poor adhesion	<ul style="list-style-type: none"> • Too much microspheres • The wrong grade of microspheres is used 	<ul style="list-style-type: none"> • The microsphere content should be 5 to 20 % dry content of total dry content • Use 007 WU and decrease the amount to half of what is used with other microsphere grades.
The screen clogs	<ul style="list-style-type: none"> • Too little glycerine • Unstable binder 	<ul style="list-style-type: none"> • Add more glycerine/propylene glycol • Exchange binder • Filter the ink
Rough print	<ul style="list-style-type: none"> • The print has not dried before expansion, the water evaporates (boils) which gives a coarser surface 	<ul style="list-style-type: none"> • Let the print dry before expansion
Smooth print	<ul style="list-style-type: none"> • The ink has dried before expansion 	<ul style="list-style-type: none"> • To achieve a coarser print surface, expand for 0.5–2 min. • Use microspheres with coarser particle size
Poor resistance	<ul style="list-style-type: none"> • The wrong ratio binder/microspheres • Poor binder 	<ul style="list-style-type: none"> • Increase the binder content (binder/microspheres > 3) • Use a binder that can be crosslinked

Expansion

Problem	Cause	Action
Poor expansion	<ul style="list-style-type: none"> • Too little microspheres in the mixture • Too low temperature • Too short time • The wrong binder - heavily self crosslinking • Too small deposit 	<ul style="list-style-type: none"> • Add more microspheres • Increase the temperature in the process to the recommended sphere temperature • Exchange the binder (guide formulations in AG.INK02) • Identify print process • Increase the solid content of the ink
Too early expansion	<ul style="list-style-type: none"> • Chemical agitation • Heat is emitted when the additives are mixed for too long • Wrong choice of microsphere grade 	<ul style="list-style-type: none"> • Identify the component affecting the microspheres • Decrease the mixing time • Select a more temperature resistant Expancel® grade

Viscosity

Problem	Cause	Action
Too high viscosity	<ul style="list-style-type: none"> • The printing ink has been stored too long (durability approximately 4 months in closed container) 	<ul style="list-style-type: none"> • Identify the thickener used
Time-related change in the viscosity of the ink	<ul style="list-style-type: none"> • Unsuitable thickener • Bivalent metal ions disturb the thickener 	<ul style="list-style-type: none"> • Identify the amount and type of microsphere and type of thickener used • Use salt-free microsphere grades • Exchange the thickener (with e.g. RM-825)

Properties of the End Product

● Adhesion

Problem	Cause	Action
The prints come loose from the substrate	<ul style="list-style-type: none"> • Incompatibility between binder and substrate 	<ul style="list-style-type: none"> • Identify the substrate • Identify the polymer in the binder • Exchange the binder
	<ul style="list-style-type: none"> • Too much microspheres in the ink 	<ul style="list-style-type: none"> • Decrease the microsphere content

● Surface

Problem	Cause	Action
Poor delustering	<ul style="list-style-type: none"> • Overexpansion of the surface layer • Too small microsphere content 	<ul style="list-style-type: none"> • Decrease the expansion temperature • 1–5 % microspheres for delustering
Inhomogeneity (white dots)	<ul style="list-style-type: none"> • See dispersion 	<ul style="list-style-type: none"> • See dispersion
Surface smoothness	<ul style="list-style-type: none"> • Moisture content at expansion - higher moisture content gives a rougher surface • Large spheres give a rougher surface and vice versa 	<ul style="list-style-type: none"> • Go through the drying conditions before expansion of the microspheres • Change to a microsphere with suitable particle size

● Color

Problem	Cause	Action
The end product is discolored at expansion	<ul style="list-style-type: none"> • Overheating has occurred at the printing process or the heating time has been too long. 	<ul style="list-style-type: none"> • Decrease the temperature or shorten the heating time.
The color of the ink fades at the use of microspheres.	<ul style="list-style-type: none"> • Volume increase at the expansion of microspheres also gives a dilution of the pigment. 	<ul style="list-style-type: none"> • Increase the pigment content (certain compensation). • Overexpand the microspheres in the surface layer.

● Other

Problem

Not able to create a desired anti-slip effect.

Cause

- Too hard binder
- Too little microspheres
- Another filler in the formula that disturbs.

Action

- Identify the components of the formulation
- Dosage of microspheres: 1 to 20 %
- Choose soft to medium soft binders.



To find out more about our microspheres,
visit our website:
nouryon.com/products/expandel-microspheres

or contact us at:
E: info.expandel@nouryon.com

© Nouryon. All rights reserved.

The information contained in this leaflet is not intended to be exhaustive and is presented in good faith and believed to be correct as of the date on which it is prepared. Persons using the information must make their own determinations and assessments as to the suitability of the relevant information for their purposes prior to taking any action based on the information. Neither Nouryon nor any of its affiliates or representatives makes any representation or warranty, expressed or implied, as to the accuracy or completeness of this document or any of the information contained herein. Nouryon and its affiliates or representatives expressly disclaim to the fullest extent permitted by law any and all liability based, in whole or in part, on the document or any information contained herein.

Nouryon, the Nouryon logo, and Expandel® microspheres are registered and/or owned trademarks of Nouryon.

12-09-2023

Nouryon

Nouryon is a global, specialty chemicals leader. Markets and consumers worldwide rely on our essential solutions to manufacture everyday products, such as personal care, cleaning goods, paints and coatings, agriculture and food, pharmaceuticals, and building products. Furthermore, the dedication of around 8,300 employees with a shared commitment to our customers, business growth, safety, sustainability and innovation has resulted in a consistently strong financial performance. We operate in over 80 countries around the world with a portfolio of industry-leading brands. Visit our website and follow us @Nouryon and on LinkedIn.

nouryon.com